



www.dreamgear.net

iSound®

dreamGEAR®

## WARRANTY CARD

All dreamGEAR/i.Sound products come with a limited warranty and have been subjected to a thorough series of tests to ensure the highest level of dependability and compatibility. It is unlikely that you will experience any problem, but if a defect should become apparent during the use of this product, dreamGEAR warrants to the original consumer purchaser that this product will be free from defects in material and workmanship for a period of 120 days from the date of your original purchase. If a defect covered by this warranty occurs, dreamGEAR, at its option, will repair or replace the product purchased at no charge. If a replacement is necessary and your product is no longer available, a comparable product may be substituted at the sole discretion of dreamGEAR.

This warranty does not cover normal wear and tear, abusive use or misuse, modification, tampering or by any other cause not related to either materials or workmanship. This warranty does not apply to products used for any industrial, professional or commercial purposes.

For service on any defective product under the 120-day warranty policy, please contact Consumer Support to obtain a Return Authorization Number.

**NOTE:** dreamGEAR will not process any defective claims without a Return Authorization Number.

### Consumer Support Hotline:

877-999-DREAM (3732) (U.S. and Canada only) or  
310-222-1045 (International)

Consumer Support Email: support@dreamgear.net

### Websites:

www.dreamgear.net  
www.isound.net

works with/compatible avec  
PSVITA™



Protect & Store Bundle  
DGPSV-3316

User's Guide



### PACKAGE CONTENTS:

- Front Screen Protector
- Back Screen Protector
- 2 Game Cases
- User's Guide/Warranty Card
- Registration Card

#### Front Screen Protector

1. Peel the layer labeled (1) from the rest of the screen protector.
2. Place the screen protector on the top screen of the PSVITA. Make sure you smooth out any bubbles with a flat card or your fingers.
3. Peel the layer labeled (2) from the screen protector.

**NOTE:** Before applying the screen protector onto your PSVITA, use a soft cloth to clean off the surface of the screen.

#### Back Screen Protector

1. Peel the layer labeled (1) from the rest of the screen protector.
2. Place the screen protector on the touchscreen located on the back of the PSVITA. Make sure you smooth out any bubbles with a flat card or your fingers.
3. Peel the layer labeled (2) from the screen protector.

**NOTE:** Before applying the screen protector onto your PSVITA, use a soft cloth to clean off the surface of the screen.

#### Game Case

Each game case can hold up to 8 PSVITA games and 2 PSVITA memory cards.



### CONTENIDO DEL PAQUETE:

- Protector de la Pantalla Frontal
- Protector de la Pantalla Trasera
- 2 Fundas para Juegos
- Guía del Usuario/Tarjeta de Garantía
- Tarjeta de Registro

#### Protector de la Pantalla Frontal

1. Retire la superficie etiquetada (1) del resto del protector de pantalla.
2. Coloque el protector sobre la pantalla superior de la PSVITA. Asegúrese de eliminar cualquier burbuja con una tarjeta plana o con los dedos.
3. Retire la superficie etiquetada (2) del protector de pantalla.

**NOTA:** Antes de aplicar el protector de pantalla sobre su PSVITA, use una gamuza de limpieza suave para limpiar la superficie de la pantalla.

#### Protector de la Pantalla Trasera

1. Retire la superficie etiquetada (1) del resto del protector de pantalla.
2. Coloque el protector de pantalla sobre la pantalla táctil situada en la parte trasera de la PSVITA. Asegúrese de eliminar cualquier burbuja con una tarjeta plana o con los dedos.
3. Retire la superficie etiquetada (2) del protector de pantalla.

**NOTA:** Antes de aplicar el protector de pantalla sobre su PSVITA, use una gamuza de limpieza suave para limpiar la superficie de la pantalla.

#### Funda para Juegos

Cada funda para juegos puede guardar hasta 8 juegos PSVITA y dos tarjetas de memoria PSVITA.



### CONTENU DU COFFRET:

- Protecteur d'Écran Frontal
- Protecteur d'Écran Arrière
- 2 Boîtes pour Jeux
- Guide d'Utilisation/Carte de Garantie
- Carte d'Enregistrement

#### Protecteur d'Écran Frontal

1. Décollez la couche nommée (1) du reste du protecteur d'écran.
2. Placez le protecteur d'écran sur l'écran frontal de PSVITA. Veillez à aplanir toutes les bulles avec une carte plate ou vos doigts.
3. Décollez la couche nommée (2) du reste du protecteur d'écran.

**REMARQUE:** Avant d'appliquer le protecteur d'écran sur votre PSVITA, utilisez le chiffon de nettoyage inclus pour nettoyer la surface de l'écran.

#### Protecteur d'Écran Arrière

1. Décollez la couche nommée (1) du reste du protecteur d'écran.
2. Placez le protecteur d'écran sur l'écran arrière tactile de PSVITA. Veillez à aplanir toutes les bulles avec une carte plate ou vos doigts.
3. Décollez la couche nommée (2) du reste du protecteur d'écran.

**REMARQUE:** Avant d'appliquer le protecteur d'écran sur votre PSVITA, utilisez le chiffon de nettoyage inclus pour nettoyer la surface de l'écran.

#### Boîte pour Jeux

Chaque boîte pour jeux peut contenir jusqu'à 8 jeux et 2 cartes mémoire PSVITA.